


NOTE: Where possible, meterboxes should be located in sheltered areas of the building. Ensure good pressure is applied when installing window tape along entire surface for a good bond to wall and meterbox surfaces

Title: Meterbox Detail (head/jamb/sill)		
	Date. March 2017	Detail No.21
	This drawing must be read in conjunction with the Plastercrete Drained & Ventilated Cladding Design Guid	